

## Safety Warnings



The lightning flash arrowhead within an equilateral triangle is intended to alert the user to the presence of non insulated, 'dangerous voltage' within the product's enclosure, that may be of sufficient magnitude to constitute risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this product.



**CAUTION:**  
This symbol indicates that the marked item may be Hot and should not be touched without proper care.

- To minimise the risk of burns and other injuries to children, position the device such that hot surfaces are out of their reach.
- To minimise the risk of fire, keep flammable materials like paper and cloth (for example, curtains) away from the hot surface.



**WARNING:**  
Do not expose this apparatus to dripping or splashing liquids, and ensure that no objects filled with liquids – such as vases – are placed on the apparatus. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

## WARNING

### DO NOT OPEN

TO PREVENT THE RISK OF ELECTRIC SHOCK,  
DO NOT REMOVE SPEAKER COVERS (OR BACKS).  
NO USER-SERVICEABLE PARTS INSIDE.  
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

## AVISQUE

POUR EVITER TOUT RISQUE DE CHOC ELECTRIQUE,  
NE PAS DEMONTER LE COUVERCLE DU HAUT PARLEUR.  
AUCUN ENTRETIEN DES PIECES INTERIEURES N'EST REQUIS.  
TOUT SERVICE D'ENTRETIEN NE DOIT ETRE EFFECTUE QUE  
PAR DU PERSONNEL D'ENTRETIEN QUALIFIE.

## CAUTION:

TO PREVENT THE RISK OF ELECTRIC SHOCK, MATCH WIDE  
BLADE OF PLUG TO WIDE SLOT. INSERT CAREFULLY.  
**ATTENTION:**  
POUR EVITER LES CHOCS ELECTRIQUES, INTRODUIRE LA  
LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE  
CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU'AU  
FOND.

## READ AND HEED IMPORTANT SAFETY WARNING ON REAR OF SPEAKER ENCLOSURE

## Warranty and Technical Support

- Please refer to the enclosed Technical Support leaflet.
- Veuillez vous reporter ci-jointe à la brochure concernant le supporte technique.
- Bitte beziehen Sie sich auf das beiliegende technische Begleitbuch.
- Consultare il depliant allegato contenente informazioni sull'assistenza tecnica.
- Consulte el folleto incluido de Asistencia Técnica.
- Zie de bijgevoegde instructies voor informatie over de technische dienst.
- Consulte o folheto de Assitência Técnica incluído.
- Vedlagt finner du en veiledning om kundestøtte.
- Katso tuotteen mukana tullutta Tekninen tuki -lehtistä.
- Var god se den bifogade Tekniska support handboken.
- Se den vedlagte tekniske support brochure.
- Prosim, sežnamte se s letakem technické podpory.
- Proszę zapoznać się z załączoną broszurą Pomoc Techniczna.
- См. прилагаемый листок Технической поддержки.
- Olvassa el a mellékelt Technikai segítőszöveget és a csatlakozási útmutatót.
- Ανατρέξτε στο ενσωκλειστο φυλλάδιο Τεχνικής υποστήριξης.



With its five compact satellite speakers and separate subwoofer with 6-channel amplification, the Creative GigaWorks ProGamer G500 is an excellent speaker system for use with Creative EAX®-enabled products. Combine it with the powerful Sound Blaster Live! family or the innovative Sound Blaster Audigy series audio cards, and experience a thrilling, high-quality 5.1 PC home theater audio experience that meets the prestigious THX® multimedia certification standard. For more information on EAX, be sure to visit [www.EAX.creative.com](http://www.EAX.creative.com).

CREATIVE®



CREATIVE  
GIGAWORKS™  
PROGAMER G500

July  
© 2005 Creative Technology Ltd. All rights reserved. The Creative logo, GigaWorks, CMSS, Sound Blaster, the Sound Blaster logo, the EAX logo, EAX, Flared DynaPort and PowerTouch are registered trademarks or trademarks of Creative Technology Ltd. in the United States and/or other countries. THX and the THX logo are trademarks or registered trademarks of THX Ltd. Used under authorisation. All other logos, brand or product names are trademarks or registered trademarks of their respective holders and are hereby recognised as such. All specifications are subject to change without notice. Use of this product is subject to a limited warranty. Actual contents may differ slightly from those pictured.

P/N 03MF404000001 Rev. A

**EN** Quick Start Guide

**FR** Démarrage Rapide

**DE** Schnellstart

**IT** Guida Quick Start

**ES** Guía Rápida

**NL** Snel aan de slag

**PT** Início Rápido

**NO** Lynstart

**FI** Pikaohje

**SV** Snabbstart

**DA** Lynstart

**CZ** Krátký Úvod

**PL** Szybki start

**RU** Краткие указания

**HU** Gyorskalauz

**EL** Οδηγός γρήγορης εκκίνησης

## Important Safety Instructions

**READ INSTRUCTIONS** - All safety and operating instructions should be read before the Creative GigaWorks ProGamer G500 amplified subwoofer/satellite system is operated.

**RETAIN INSTRUCTIONS** - The safety and operating instructions should be retained for future reference.

**HEED WARNINGS** - All warnings on the subwoofer and in the operating instructions should be adhered to.

**FOLLOW INSTRUCTIONS** - All operating and usage instructions should be followed.

**CLEANING** - Unplug the subwoofer from the wall outlet or other power source before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a dry cloth for cleaning.

**ATTACHMENTS** - Do not use attachments not recommended by Creative Technology as they may cause hazards.

**WATER AND MOISTURE** - Do not use the subwoofer near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

**ACCESSORIES** - Do not place the Creative GigaWorks ProGamer G500 system on an unstable cart, stand, tripod, bracket, or table. The subwoofer or satellites may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by Creative Technology, or sold with the product. Any mounting of the satellites or subwoofer should follow the manufacturer's instructions, and should use a mounting accessory recommended by Creative Technology.

**VENTILATION** - Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the subwoofer and to prevent it from overheating; and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. The subwoofer should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or Creative Technology's instructions have been adhered to.

**HEAT** - The subwoofer should be situated away from heat sources such as radiators, heat registers, stoves, and other products (including amplifiers) that produce heat.

**POWER SOURCES** - The subwoofer should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power or other sources, refer to the operating instructions.

**POLARISATION** - The subwoofer may be equipped with a polarised alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarised plug.

**POWER-CORD PROTECTION** - Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the subwoofer.

**LIGHTNING** - For added protection for the Creative GigaWorks ProGamer G500 system during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage to the subwoofer due to lightning and power line surges.

**OVERLOADING** - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

**OBJECT AND LIQUID ENTRY** - Never push objects of any kind into the subwoofer through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the subwoofer.  
**SERVICING** - Do not attempt to service the subwoofer your self as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.


**DAMAGE REQUIRING SERVICE** - Unplug the subwoofer from the wall outlet or other power source and refer servicing to qualified service personnel under the following conditions:  
a) When the power-supply cord or plug is damaged.  
b) If liquid has been spilled, or objects have fallen into the subwoofer.  
c) If the subwoofer has been exposed to rain or water.  
d) If the subwoofer does not operate normally by following the operating instructions; or exhibits a distinct change in performance.  
e) If the product has been dropped or damaged in any way.

**REPLACEMENT PARTS** - When replacement parts are required, be sure the service technician has used replacement parts specified by Creative Technology, or have the same characteristics as the original part. Unauthorised substitutions may result in fire, electric shock, or other hazards.

**SAFETY CHECK** - Upon completion of any service or repairs to the Creative GigaWorks ProGamer G500 system, ask the service technician to perform safety checks to determine that the Creative GigaWorks G500 system is in proper operating condition.

**WALL OR CEILING MOUNTING** - The Creative GigaWorks ProGamer G500 satellites should be mounted to a wall or ceiling only as recommended by Creative Technology.

- (Optional) Rear satellite floor stands are sold separately. For more information, please refer to <http://www.europe.creative.com>
- (Facultatif) Des socles pour haut-parleurs satellites arrières sont disponibles séparément. Pour plus d'informations, visitez notre site Web à l'adresse <http://www.europe.creative.com>
- (Zusätzliche) hinterer Satelliten Bodenständer werden separat verkauft. Mehr Informationen erhalten Sie unter <http://www.europe.creative.com>
- (Opzionale) I piedistalli per i satelliti posteriori sono venduti separatamente. Per ulteriori informazioni, per favore fare riferimento all'indirizzo <http://www.europe.creative.com>
- (Optional) Puede adquirir por separado soportes para los altavoces traseros. Para más información, visite nuestro sitio en <http://www.europe.creative.com>
- (Optioneel) Satellite steunen voor de achter satellieten worden apart verkocht. Voor meer informatie, gelieve u te richten tot <http://www.europe.creative.com>
- (Optional) Soportes de satélite traseiros poderão ser adquiridos separadamente. Para mais informações, por favor consulte o nosso Web site <http://www.europe.creative.com>
- (Valgritt) Gulvstativ til bakre høyttalere selges separat. Besøk vårt Web-område <http://www.europe.creative.com> hvis du vil ha mer informasjon
- (Lisävaruste) Takasatelliittikaiuttimien jalustat myydään erikseen. Lisätietoja Internet-soihteesta: <http://www.europe.creative.com>
- (Tillbehör) Ställningar för bakre satellithögtalare säljs separat. Mer information hittar du på vår webbplats <http://www.europe.creative.com>
- (Ekstraudstyr) Stativer til baghøjttalere sælges separat. For mere information, se venligst <http://www.europe.creative.com>
- (Volitelná) Stojany zadních satelitních reproduktorů. Podrobnosti najdete na našem webovém serveru <http://www.europe.creative.com>
- (Opzionale) Stativy do tylných glosníků satelitarnych sprzedawane są osobno. Więcej informacji na ten temat można znaleźć na <http://www.europe.creative.com>
- (Необязательно) Подставки для задних саателитных громкоговорителей продаются отдельно. Дополнительные сведения приведены на веб-узле по адресу <http://www.europe.creative.com>
- (Opzionale) A hátsó szatellit hangfalak állványait külön kell megvásárolnia. Ha további információra van szüksége, keresse fel a <http://www.europe.creative.com> webhelyet.
- (Προαιρετικά) Τα πίσω περιφερειακά σπριγύματα εάφους πωλούνται ξεχωριστά. Για περισσότερες πληροφορίες, ανατρέξτε στην ηλεκτρονική διεύθυνση <http://www.europe.creative.com>



**EN** English

## Specifications

**Creative GigaWorks ProGamer G500**  
Satellite speaker:  
**36 watts RMS per channel**  
Centre Satellite Speaker:  
**36 watts RMS**  
Subwoofer:  
**130 watts RMS**  
Signal-to-Noise Ratio:  
**85dB**  
Frequency Response:  
**35Hz - 20kHz**

## Important Notice

The serial number for your Creative GigaWorks ProGamer G500 is located on the subwoofer. Please write this number down and keep it in a secure place.

**FI** Suomi

## Tekniset tiedot

**Creative GigaWorks ProGamer G500**  
Satelliittikaiutin:  
**36 wattia RMS/kanava**  
Keskuskautin:  
**36 wattia RMS**  
Subwoofer:  
**130 wattia RMS**  
Signaali-kohinasuhde:  
**85dB**  
Taajuualue:  
**35–20 000 Hz**

**Tärkeä huomautus**  
Creative GigaWorks ProGamer G500:n sarjanumero on subwoofer-kaiuttimessa. Kirjoita tämä numero ylös ja säilytä se huolellisesti.

**FR** Français

## Spécifications

**Creative GigaWorks ProGamer G500**  
Haut-parleur satellite:  
**36 watts RMS par canal**  
Satellite central:  
**36 watts RMS**  
Caisson de basse:  
**130 watts RMS**  
Rapport signal/bruit:  
**85dB**  
Réponse en fréquence:  
**35Hz - 20kHz**

## Avis important

Le numéro de série de votre GigaWorks ProGamer G500 de Creative se trouve sur le caisson de basses. Veuillez prendre ce numéro en note et le conserver en lieu sûr.

**SV** Svenska

## Uppgifter

**Creative GigaWorks ProGamer G500**  
Satelliithögtalare:  
**36 Watt effektivvärde per kanal**  
Centersatelliithögtalare:  
**36 Watt effektivvärde**  
Subwoofer:  
**130 Watt effektivvärde**  
Signal/störingsförhållande:  
**85dB**  
Frekvensområde:  
**35Hz till 20kHz**

**Viktigt meddelande**  
Serienumret för din Creative GigaWorks ProGamer G500 hittar du på subwoofern. Noter numret ned, og oppbevar det et sikkert sted.

**DE** Deutsch

## Technische Daten

**Creative GigaWorks ProGamer G500**  
Satellitenlautsprecher:  
**36 Watt RMS pro Kanal**  
Satellit Center:  
**36 Watt RMS**  
Tiefenlautsprecher:  
**130 Watt RMS**  
Rauschabstand:  
**85dB**  
Frequenzgang:  
**35Hz bis 20kHz**

## Wichtiger Hinweis

Die Seriennummer des Creative GigaWorks ProGamer G500 befindet sich auf dem Subwoofer. Notieren Sie diese Nummer, und bewahren Sie sie an einem sicheren Ort auf.

**DA** Dansk

## Specifikationer

**Creative GigaWorks ProGamer G500**  
Satelliithögtalere:  
**36 Watt RMS pr. kanal**  
Midterste satellit:  
**36 Watt RMS**  
Subwoofer:  
**130 Watt RMS**  
Signal/støjforhold:  
**85dB**  
Frekvensrespons:  
**35Hz til 20kHz**

**Vigtig meddelelse**  
På Creative GigaWorks ProGamer G500 er serienummeret anbragt på subwooferen. Noter nummeret ned, og opbevar det et sikkert sted.

**IT** Italiano

## Specifiche tecniche

**Creative GigaWorks ProGamer G500**  
Altoparlante satellite:  
**36 Watt RMS per canale**  
Satellite centrale:  
**36 Watt RMS**  
Subwoofer:  
**130 Watt RMS**  
Rapporto segnale-rumore (SNR):  
**85dB**  
Risposta frequenza:  
**da 35Hz a 20kHz**

## Avviso importante

Il numero di serie di Creative GigaWorks ProGamer G500 è situato sul subwoofer. Annotare questo numero e conservarlo in un posto sicuro.

**CZ** Česky

## Specifikace

**Creative GigaWorks ProGamer G500**  
Satelitní reproduktor:  
**RMS 36 W na kanál**  
Centrální satelitní reproduktor:  
**RMS 36W**  
Basový reproduktor (Subwoofer):  
**RMS 130W**  
Odstup signál/šum:  
**85dB**  
Frekvenční rozsah:  
**35Hz až 20kHz**

**Důležité upozornění**  
Sériové číslo zařízení Creative GigaWorks ProGamer G500 je umístěno na subwooferu. Toto číslo si poznamenejte a uložte je na bezpečném místě.

**ES** Español

## Especificaciones

**Creative GigaWorks ProGamer G500**  
Altavoz auxiliar:  
**36 vatios de carga eficaz por canal**  
Altavoz satélite central:  
**36 watt RMS**  
Subwoofer:  
**130 vatios de carga eficaz**  
Relación de señal a ruido:  
**85dB**  
Respuesta de frecuencias:  
**35Hz a 20kHz**

## Aviso importante

El número de serie para Creative GigaWorks ProGamer G500 se encuentra en el altavoz de graves. Anote este número y guárdelo.

**PL** Polski

## Specyfikacje

**Creative GigaWorks ProGamer G500**  
Głośnik satelitalny:  
**RMS 36 W na kanał**  
Centralny satelitalny głośnik:  
**RMS 36W**  
Głośnik niskotonowy (Subwoofer):  
**RMS 130W**  
Odstup sygnał/śum:  
**85dB**  
Pasmo przenoszenia:  
**35Hz do 20kHz**

**Ważna informacja**  
Numer seryjny głośnika Creative GigaWorks ProGamer G500 jest podany na głośniku niskotonowym. Numer ten należy zapisać i przechowywać w bezpiecznym miejscu.

**NL** Nederlands

## Specificaties

**Creative GigaWorks ProGamer G500**  
Satelliithoofdluspreker:  
**36 watt RMS per kanaal**  
Satelliet midden:  
**36 watt RMS**  
Subwoofer:  
**130 watt RMS**  
Signaal/ruisverhouding:  
**85dB**  
Frequentieweergave:  
**35Hz tot 20kHz**

## Belangrijke kennisgeving

U vindt het serienummer voor uw Creative GigaWorks ProGamer G500 op de subwoofer. Noteer dit nummer en bewaar het op een veilige plaats.

**RU** Русский

## Технические параметры

**Creative GigaWorks ProGamer G500**  
Сателлитный громкоговоритель:  
**36 Вт эфф на канала**  
Центральный динамик:  
**36 Вт эфф**  
Низкочастотный громкоговоритель:  
**130 Вт эфф**  
Отношение сигнал/шум:  
**85дБ**  
Диапазон воспроизводимых частот:  
**от 35Гц до 20кГц**

**Важная информация**  
Серийный номер вашей системы Creative GigaWorks ProGamer G500 указан на низкочастотной колонке. Запишите этот номер и храните в надежном месте.

**PT** Português

## Especificações

**Creative GigaWorks ProGamer G500**  
Coluna satélite:  
**36 watts RMS por canal**  
Satélite central:  
**36 watts RMS**  
Subwoofer:  
**130 watts RMS**  
Relação sinal/ruído:  
**85dB**  
Resposta de frequência:  
**35Hz a 20kHz**

## Aviso importante

O número de série do sistema de colunas Creative GigaWorks ProGamer G500 está localizado no subwoofer. Anote este número e guarde-o em local seguro.

**HU** Magyar

## Műszaki adatok

**Creative GigaWorks ProGamer G500**  
Szatellit hangszóró:  
**36 W RMS csatornánként**  
Középső szatellit hangszóró:  
**36 watt (RMS)**  
Mélyszugárzó:  
**130 watt (RMS)**  
Jel/zaj arány:  
**85dB**  
Frekvenciataromány:  
**35 Hz - 20 kHz**

**Fontos**  
Creative GigaWorks ProGamer G500 rendszerének sorozatszámát a mélyszugárzóon található. Írja fel ezt a számot, és tartsa biztos helyen.

**NO** Norsk

## Spesifikasjoner

**Creative GigaWorks ProGamer G500**  
Satelliithoofltalar:  
**36 W RMS per kanal**  
Midtre satellitt:  
**36 W RMS**  
Subwoofer:  
**130 W RMS**  
Signalstøyfrekvens:  
**85dB**  
Frekvensgang:  
**35Hz til 20kHz**

## Viktig merknad


Serienummeret for Creative GigaWorks ProGamer G500 befinner seg på subwooferen. Skriv ned dette nummeret, og oppbevar det på et sikkert sted.

**EL** Ελληνικά



## Προδιαγραφές

**Creative GigaWorks ProGamer G500**  
Περιφερειακό ηχείο:  
**36 watt RMS ανά κανάλι**  
Κεντρικό περιφερειακό ηχείο:  
**36 watt RMS**  
Subwoofer:  
**130 watt RMS**  
Αναλογία σήματος-παραεμβόλων:  
**85dB**  
Ανταπόκριση συχνότητας:  
**35Hz - 20kHz**  
12V AC 2.9A.

**Σημαντική σημείωση**  
Ο σειριακός αριθμός του Creative GigaWorks ProGamer G500 βρίσκεται επάνω στο subwoofer. Σημειώστε τον αριθμό αυτόν και φυλάξτε τον σε ασφαλές μέρος.



For placement in front of a monitor



For placement on top of a monitor

